



SINGLE PACKAGE ROOFTOP UNIT GAS HEATING / ELECTRIC COOLING

PARTS REPLACEMENT INFORMATION GUIDE

COMPRESSOR GROUP

Compressor
Crankcase Heater

FILTER GROUP

Filters
Filter Track

INDOOR BLOWER GROUP

Blower Assembly
Blower Stator
Blower Motor
Blower Rotor

OUTDOOR FAN GROUP

Outdoor Motor
Outdoor Fan Blade
Outdoor Fan Grill
Outdoor Fan Air Flow Extension

CASING GROUP

Top Cover
Control Box Cover (inner)
Blower Access Panel
Compressor Access Panel
Filter Access Panel

AIR FLOW CASING

Harness Assembly
Flow Control Ring
Mount Ring

ELECTRICAL GROUP

Control Box
Compressor Plug/Harness
Limit Switch(es)
Unit Control Board
Capacitor
Transformer
Wiring Harness
Compressor Contactor
Indoor Motor Contactor
Outdoor Motor Contactor
Over-temperature Switch
Low Voltage Terminal Board
Integrated Gas Control Board
Fuse
Circuit Breaker

GAS CONTROL GROUP

Manifold
Burner
Orifice
Flame Sensor
Igniter
Gas Valve

GAS HEAT INDUCER GROUP

Inducer Pressure Switch
Inducer Motor
Inducer Housing
Inducer Motor Capacitor
Inducer Wheel

HEAT EXCHANGER GROUP

Heat Exchanger Assembly

COIL AND PIPING GROUP

Indoor Coil
Outdoor Coil
Indoor Coil Liquid Header

Part Information

To obtain information on parts, please consult installing dealer, go to WWW.TOTALINE.com and enter zip code to find the nearest store, or contact:

Consumer Relations Department
P.O. Box 4952
Syracuse, New York 13221
1-800-428-4326

Example of Model Number

UNIT HEAT TYPE	TIER/ MODEL	HEAT SIZE	REFRIG. OPTIONS	COOLING TONS	OPTIONS	VOLTAGE	DESIGN REVISION	CONTROLS	OPTIONS	BRAND/ PACKAGING
48	FC	D	A	06	A1A	5	-	0	A0A	0

WARNING

Improper installation, adjustment, alteration, service, or maintenance can cause personal injury, property damage, or death. Consult a qualified installer, service agency, or local gas supplier for information or assistance. The qualified installer or service agency must use only factory-authorized replacement parts, kits, or accessories when modifying this product.