



48/50A2,A3,A4,A5,AJ,AK,AW,AY020-060 Power Exhaust, Barometric Relief, and Conversion Package Accessories

Installation Instructions

Power Exhaust Part Numbers: CRPWREXH033A00, CRPWREXH034A00,
CRPWREXH035A00, CRPWREXH036A00

Barometric Relief Part Number: CRBARRLF003A01

Conversion Package Numbers: CRPECONV005A00, CRPECONV006A00

SAFETY CONSIDERATIONS

Installation and servicing of air-conditioning equipment can be hazardous due to system pressure and electrical components. Only trained and qualified service personnel should install, repair, or service air-conditioning equipment.

Untrained personnel can perform the basic maintenance functions of cleaning coils and filters and replacing filters. All other operations should be performed by trained service personnel. When working on air-conditioning equipment, observe precautions in the literature, tags and labels attached to the unit, and other safety precautions that may apply.

⚠ WARNING

Turn off main power to the unit and tag disconnect switch before performing service or maintenance operations. Electrical shock could cause personal injury or death.

GENERAL

IMPORTANT: The power exhaust accessory requires the use of the economizer. Power exhaust will not operate without the use of an economizer.

An economizer is required to install the barometric relief or power exhaust accessories on 48/50A Series units. Refer to Table 1 for a complete list of parts contained in each kit.

The power exhaust blowers are shipped assembled and packaged one hood assembly per container.

NOTE: The 48/50A020-050 units require 2 assemblies per unit; 48/50A051 and 060 units require 3 assemblies per unit.

Each hood assembly has 2 power exhaust blowers. Brackets, wires and extra gasket screws are also included in the package.

In addition to the power exhaust accessory, to convert a 48/50A Series unit the following accessories are required:

- To convert a constant volume unit without power exhaust or with non-modulating power exhaust to a modulating power exhaust unit, conversion kits CRPECONV005A00 and CRPECONV006A00 must be installed.

NOTE: If the unit has the factory-installed hot gas bypass (HGBP) option (also referred to as a minimum load valve), then the CRPECONV005A00 kit will not be required.

- To convert a VAV unit without power exhaust to a modulating power exhaust unit, conversion kit CRPECONV006A00 must be installed.

POWER EXHAUST PACKAGE USAGE

UNIT	VOLTAGE	PART NUMBER	UNIT SIZE	NO. REQUIRED
48/50A*	208/230 V	CRPWREXH033A00	020-050	2
			051, 060	3
	400 V and 460 V	CRPWREXH034A00	020-050	2
			051, 060	3
	575 V	CRPWREXH035A00	020-050	2
			051, 060	3
	380 V	CRPWREXH036A00	020-050	2
			060	3

*For 48/50A Series units, to convert a constant volume unit with no power exhaust or with non-modulating power exhaust to a modulating power exhaust unit, accessory conversion kits CRPECONV005A00 and CRPECONV006A00 must be purchased and installed in addition to the power exhaust accessory. If the unit has the factory-installed hot gas bypass (HGBP) option, then the

CRPECONV005A00 kit will not be required. To convert a VAV unit without power exhaust to a modulating power exhaust unit, accessory conversion kit CRPECONV006A00 must be purchased and installed in addition to the power exhaust accessory.

CAUTION

When removing panels from the unit, be careful not to damage roof or other surfaces with the panels.

INSTALLATION

Power Exhaust

VERTICAL DISCHARGE UNITS (48/50A2,A3,AJ,AK)

1. Unpack accessory packages.
NOTE: For 48/50A020-050 units, 2 accessory packages are required. For 48/50A051 and 060 units, 3 accessory packages are required. Installation will be repeated for each package.
2. Disconnect power to unit.
3. If the economizer hoods have been installed, perform the following:
 - a. Remove the filters from the economizer hoods.
 - b. Remove the 5 screws from the bottom of the economizer and the 3 screws on each side of the economizer. Save screws.
 - c. Remove the upper panel by pulling out the economizer assembly at the bottom to release panel. Save all screws from panel.
 - d. Remove the lower panel. Save all screws.
 - e. There are 2 economizer hoods and 4 panels on size 020-050 units. There are 3 economizer hoods and 6 panels on size 051 and 060 units. Repeat this step for each economizer hood and panel.

If the economizer hoods have not been installed, remove the upper and lower panels covering each return air section. See Fig. 1. Save all screws. There are 2 economizer hoods and 4 panels on size 020-050 units. There are 3 economizer hoods and 6 panels on size 051 and 060 units. Repeat this step for each economizer hood and panel.

4. Install top support panel (provided). Use 3 screws on each side and 5 screws across top removed from existing upper panel. If removed in Step 3, install 3 screws on economizer sides and replace economizer filter. See Fig. 2.
5. Place hood assembly close to unit. Plug the motor harness into mating plug in the center damper support (see Fig. 3-5).

6. Set the hood assembly into the opening, top lip first underneath the support panel installed in Step 4.
7. Lift the assembly to allow bottom corner tabs to hook over the base rail (see Fig. 6).
8. Install 3 screws (saved in Step 3) along the top of hood and through support panel.
9. Install the two side blockoff brackets on each side of the hood assembly with 6 gasketed screws provided (3 each side). See Fig. 6.
10. Install 3 gasketed screws (saved in Step 3) along the bottom of power exhaust assembly.
11. Repeat Steps 3 through 10 for the other hood assemblies.
12. Remove tape from damper blades.
13. Complete Configuration section on page 3.

HORIZONTAL DISCHARGE UNITS (48/50A4,A5,AW,AY)

1. Unpack accessory package. The support panel is not used and may be discarded.
2. Disconnect power to unit.
3. Provide openings 45 1/4-in. wide by 23 3/16-in. high in the side of the return air duct for the number of accessories ordered. See Fig. 7. Ensure that the transition required to accommodate these openings begins at least 3.5 feet away from the outdoor-air hood. Any obstruction closer than 3.5 feet will interfere with the airflow and result in rain entering the hood through the filters. See Fig. 8.
4. Drill engagement holes for 1/4-in. screws around openings as shown in Fig. 7.
5. Place first hood assembly close to openings in ductwork, plug extension harness into one end of the motor harness. Plug the other end of the extension harness into the mating plug in the center damper support (see Fig. 3-5).

NOTE: Two extension harnesses are supplied in the kit (a 120-in. and a 190-in.). The 190-in. harness may be required when 3 packages are installed as the distance from the unit may be greater than 120 inches.

6. Set the hood assembly into the opening, top lip first.
7. Lift the assembly to allow bottom corner tabs to hook over the opening in ductwork.
8. Install 3 gasketed screws (provided) along the top of hood.
9. Install two side blockoff brackets on each side of the hood assembly with 6 gasketed screws (3 each side) provided.

Table 1 — Power Exhaust/Barometric Relief Parts List

ACCESSORY	ITEM DESCRIPTION (QUANTITY)
CRBARRLF003A01	Relief Damper Assembly
	Seal Strip — 1/8" x 3/4" x 84"
	Seal Strip — 1/8" x 1 5/16" x 51"
	Screw — 1/4"-14 x 3/4" (16)
	Side Blockoff — 48EJ500314 (2)
	Support Panel — 48EJ500276 (1)
CRPWREXH033A00, CRPWREXH034A00, CRPWREXH035A00, CRPWREXH036A00	Power Exhaust Assembly
	Support Panel — 48EJ500276 (1)
	Side Blockoff — 48EJ500314 (2)
	Seal Strip — 1/8" x 3/4" x 42" (1)
	Seal Strip — 1/8" x 1 5/16" x 21" (3)
	Gasketed Screws (12)
CRPECONV005A00	Extension Harness — 120"
	Extension Harness — 190"
CRPECONV006A00	Economizer Board — 50ZZ401127
CRPECONV006A00	Building Pressure Transducer — HK05ZG022
	Control Tube (2)

Barometric Relief Damper

1. Remove return air section panel. Save screws for reuse. See Fig. 1.
2. Position the barometric relief assembly at return air section of unit. Add seal strip to the edges of the hood assembly. See Fig. 14. The long piece of seal strip is for the top and bottom. The short piece is for the two sides.
3. Place the barometric relief assembly into the unit. The accessory should pivot on the unit end panel. See Fig. 15.
4. Fold barometric relief assembly back into the unit. See Fig. 16.
5. Install the side blockoffs using the screws included (no. 14-10 x $\frac{7}{8}$ -in.). Be sure to properly position the hood. See Fig. 17.
6. Tilt the assembly out of the unit and into final operating position. See Fig. 18.
7. Secure the assembly using the screws removed from Step 1.
8. Two barometric relief packages are used for 48/50A020-050 units. Three barometric relief packages are used for 48/50A051 and 060 units. Repeat Steps 1-7 for additional barometric relief dampers.




Fig. 14 — Hood Assembly




Fig. 15 — Pivot Point on Unit Panel




Fig. 16 — Power Exhaust/Relief Damper Assembly




Fig. 17 — Blockoff and Hood Positioning




Fig. 18 — Assembly in Operating Position